

# Fms KinEASE™ FP Fluorescein Green Assay

Catalog # 32-068

Sufficient reagents for two 384-well plates per kit.

<b>Contents</b>	<b>Page</b>
I. STORAGE AND STABILITY	2
II. ASSAY OVERVIEW	2
III. SYSTEM COMPONENTS	3
A. Provided Kit Components	3
B. Recommended Buffers	3
IV. ASSAY PROCEDURE	4
A. Preparation of Assay Solutions	4
B. Protocol	5
V. APPENDIX A – Assay Optimization	6



sales orders 800 233 3991  
call collect from outside the u.s. 434 975 4300  
tech support 800 548 7853  
fax orders 866 831 3991  
www.upstate.com

**FOR IN VITRO RESEARCH USE ONLY.  
NOT RECOMMENDED OR INTENDED  
FOR DIAGNOSIS OF DISEASE IN  
HUMANS.  
DO NOT USE IN HUMANS.**

## I. STORAGE AND STABILITY

**Storage:** Upon receipt, store individual components at recommended temperatures. Store the 384-well plates at room temperature. Store all other components at -20°C.

**Stability:** Components stable for 6 months from date of shipment if stored and handled correctly. We recommend that all enzymes to be used with this kit are stored as aliquots and a fresh aliquot used for each experiment.

## II. ASSAY OVERVIEW

In this assay, a phosphorylated peptide has been labeled with a green fluorescent dye. This phosphorylated tracer has a low molecular weight and thus a low fluorescence polarization value. The phosphorylated tracer binds to a phospho-specific antibody to form a high molecular weight complex with a high polarization value.

In a kinase reaction, a peptide or a protein substrate (non-fluorescently labeled) is phosphorylated by the kinase in the presence of ATP and Magnesium to form a phosphorylated product. This phosphorylated product competes with the tracer for binding to the phospho-specific antibody. As increasing amounts of phosphorylated product are formed from the kinase reaction, there is a reduction in the binding of tracer to antibody resulting in a decrease in the fluorescence polarization value.

Fms KinEASE™ FP Fluorescein Green Assay supplied in this kit offers a method for assaying Fms using a preferred substrate and a generic detection system.



**Related Product:** Fms, Catalog # 14-551

### III. SYSTEM COMPONENTS

#### A. Provided Kit Components

Prior to use, each reagent should be vortexed, and then centrifuged to collect residual liquid trapped in the vial cap. **Please note the TK Tracer solution is light sensitive.**

Reagent	Catalog #	Stock	Volume Supplied	Storage
TK Substrate 2	12-553	100mM	30µl	-20°C
TK Antibody	35-004	20X	237µl	-20°C
TK Tracer – Fluorescein	20-289	100X	48µl	-20°C
10X KinEASE™ Buffer	20-302	10X	5ml	-20°C
10X Detection Buffer	20-308	10X	3ml	-20°C
MgCl <sub>2</sub>	20-303	1M	500µl	-20°C
MnCl <sub>2</sub>	20-309	0.1M	500µl	-20°C
DTT	20-265	1M	450µl	-20°C
ATP	20-306	10mM	300µl	-20°C
EDTA	20-307	0.5M	2ml	-20°C
384 Well KinEASE™ Plate	30-014		2 plates	RT

#### B. Recommended Buffers

Buffer	5X Buffer
Reaction Buffer	250mM HEPES pH 7.2, 0.05% BSA (Bovuminar®, Chemicon Catalog # 3225-80), 25mM MgCl <sub>2</sub> , 5mM MnCl <sub>2</sub>
Detection Buffer	250mM HEPES pH 7.2, 0.5% Tween®-20, 5mM DTT (DTT to be added immediately prior to use)

It is recommended that the MgCl<sub>2</sub> final reaction concentration should not exceed 5mM in the reaction (*i.e.*, 25mM in the 5X Reaction Buffer). If a higher concentration of MgCl<sub>2</sub> is required, then do not exceed 10mM MgCl<sub>2</sub> (*i.e.*, 50mM in the 5X Reaction Buffer) and run an enzyme reaction with stop mix and detection mix added prior to ATP addition to confirm that the reaction is stopped under these conditions.

Individual buffer components should be stored at -20°C until ready to use. The 10X KinEASE™ Buffer (Catalog # 20-302) is used to prepare 5X Reaction Buffer working stock to ensure a final 1X buffer concentration in the assay. Working buffers should be stored at 4°C until ready to use. If long-term storage (one week to six months) is required, DTT should be omitted until assay is to be performed and sodium azide added to the 5X buffer at a final concentration of 0.05%.

## IV. ASSAY PROCEDURE

**Safety Warnings and Precautions:** The Fms KinEASE™ FP Fluorescein Green Assay is designed for research use only. All chemicals should be considered potentially hazardous and principles of good laboratory practice should be followed.

### A. Preparation of Assay Solutions

Prepare sufficient volume of each solution based on the number of assays to be performed, plus a slight overage to account for pipetting inaccuracies (either 10-20% extra or one extra assay point is generally sufficient). **Note:** A precipitate may be observed in the thawed 0.5M EDTA pH 7.2 (Catalog # 20-307). Warm the tube to 37°C for 15 minutes and vortex to bring into solution.

#### Reaction Component Preparation

- 5X Reaction Buffer:** For 1ml of 5X Reaction Buffer combine 425µl water, 500µl 10X KinEASE™ Buffer, 25µl 1M MgCl<sub>2</sub>, and 50µl 0.1M MnCl<sub>2</sub>. The total amount of 5X Reaction Buffer required will depend upon the number of experimental assay points. The 1ml volume should be scaled up (or down) according to the particular requirements of the experiment.
- 1X Reaction Buffer (for use in the No Enzyme Wells, Buffer Control Wells and Tracer Control Wells):** Prepare the 1X Reaction Buffer by diluting the 5X Reaction Buffer 5-fold with water (e.g., for 1ml of 1X Reaction Buffer combine 800µl water and 200µl 5X Reaction Buffer).
- 2.5X ATP Working Solution:** Prepare a 250µM ATP Working Solution in 1X Reaction Buffer (e.g., for 1ml of the 2.5X ATP Working Solution combine 775µl water, 200µl 5X Reaction Buffer, and 25µl 10mM ATP). 10µl of the 2.5X ATP Working Solution is required per well.
- 5X TK Substrate 2 Working Solution:** Prepare a 500µM TK Substrate 2 Working Solution in 1X Reaction Buffer (e.g., for 1ml of TK Substrate 2 Working Solution combine 795µl water, 200µl 5X Reaction Buffer and 5µl of 100mM TK Substrate 2). 5µl of 5X TK Substrate 2 Working Solution is required per well.
- 2.5X Fms Working Solution:** Prepare the Fms Working Solution in 1X Reaction Buffer at a concentration of 2.5X the required final reaction concentration. 10µl of Fms Working Solution is required per well.

#### Detection Component Preparation

- 5X Detection Buffer:** Prepare the 5X Detection Buffer by diluting the 10X Detection Buffer 2-fold and adding DTT to a concentration 5mM (e.g. for 1ml of 5X Detection Buffer combine 495µl water, 500µl of 10X Detection Buffer and 5µl of 1M DTT).
- 1X Detection Buffer (for use in the Buffer Control Wells and Tracer Control Wells):** Prepare the 1X Detection Buffer by diluting the 5X Detection Buffer 5-fold with water (e.g., for 1ml of 1X Detection Buffer add 200µl 5X Detection Buffer to 800µl water).
- TK Stop Mix:** Prepare TK Stop Mix containing TK Tracer and EDTA in 1X Detection Buffer by diluting the TK Tracer 100-fold and adding EDTA to a concentration of 140mM (e.g., for 1ml of TK Stop Mix combine 510µl water, 280µl 0.5M EDTA pH 7.2, 200µl 5X Detection Buffer and 10µl 100X TK Tracer). 5µl of TK Stop Mix is required per well.
- TK Antibody Detection Mix:** Prepare TK Antibody Detection Mix containing TK Antibody in 1X Detection Buffer by diluting the TK Antibody 20-fold (e.g., for 1ml of TK Antibody Detection Mix combine 750µl water, 200µl 5X Detection Buffer and 50µl 20X TK Antibody). 5µl of TK Antibody Detection Mix is required per well.

## B. Protocol

1. Set up Reactions as detailed below.

### No Enzyme Wells

5µl TK Substrate 2 Working Solution  
10µl 1X Reaction Buffer  
10µl ATP Working Solution

### Plus Enzyme Wells

5µl TK Substrate 2 Working Solution  
10µl Fms Working Solution  
10µl ATP Working Solution

(The reactions are started by addition of the 10µl ATP Working Solution).

If required, 0.5µl DMSO may be added to the well to simulate compound addition.

2. Incubate reactions for the required length of time at the appropriate temperature. **Note:** Optimum kinase reaction incubation time and temperature should be determined by the end user. Typical kinase reaction conditions used at Upstate are 30-60 minutes at room temperature with constant agitation.
3. Stop the reactions by adding 5µl/well TK Stop Mix.
4. Add 5µl/well TK Antibody Detection Mix. **Note:** TK Stop Mix and TK Antibody Detection Mix may be combined and added as 10µl/well.

The following control wells should be set up for each experiment

### Buffer Control Wells

25µl 1X Reaction Buffer  
10µl 1X Detection Buffer

### Tracer Control Wells

25µl 1X Reaction Buffer  
5µl TK Stop Mix  
5µl 1X Detection Buffer

5. Incubate the plate for a minimum of 4 hours at room temperature (assay signal is stable for up to 24 hours).
6. Read plate on a Fluorescence Polarization Reader. The end user must optimize their instrument parameters for optimal assay sensitivity. Recommended parameters for the MDC Analyst AD used at Upstate are as follows:

**Method:** *Fluorescence Polarization*

**Excitation:** *485nm (bw20)*

**Emission:** *530nm (bw25)*

**Mirror:** *Dichroic 505*

**Lamp:** *Continuous*

**Z-height:** *3mm (to be determined for individual readers)*

**Readings per well:** *1*

**Integration time:** *100000µsec*

**Attenuator:** *out*

**PMT setup:** *Smartread Sensitivity 2*

**Excitation Polarizer:** *S (static)*

**Emission Polarizer:** *SP (dynamic)*

**G Factor:** *(to be determined for individual readers)*

Select Buffer Control Wells for background subtraction.

## V. APPENDIX A - Assay Optimization

### Determination of Enzyme Concentration for Screening

Using the optimized assay conditions, a suitable enzyme concentration for screening applications may then be determined by following the procedure outlined below.

Set up an enzyme titration with two-fold serial dilutions of enzyme and appropriate controls (No Enzyme Wells, Tracer Control Wells and Buffer Control Wells) according to the standard assay protocol.

Analyze the results obtained by plotting a graph of enzyme concentration (Units/ml) vs. Fluorescence Polarization (mP) (see below for example).

Determine the EC<sub>70</sub> mP using the following formula:

$$EC_{70} \text{ mP} = ((\text{No Enzyme Control} - \text{Tracer Control}) \times 0.3) + \text{Tracer Control}$$

From the graph of enzyme concentration (Units/ml) vs. Fluorescence Polarization (mP) determine the concentration of enzyme that correlates to the EC<sub>70</sub> mP value calculated above. This enzyme concentration (EC<sub>70</sub> Units/ml) is recommended for screening applications.

