

MATERIAL SAFETY DATA SHEET

Product: **Mouse Adiponectin RIA Kit** Catalog #: **MADP-60HK**

Composition/Information of Ingredients

<u>Component</u>	<u>Catalog #</u>	<u>Ingredients</u>	<u>See Below</u>
10X Assay Buffer (pH 7.5, Colorless)	AB-10XP	Miscellaneous Buffers/Salts	1
		Sodium Azide (NaN ₃)	2
Adiponectin Tracer (pH 7.5, Red)	9060-HK	¹²⁵ I-Adiponectin (<3uCi, <111kBq)	3
		Assay Buffer (as above)	4
		Inert Coloring	1
Adiponectin Standard (pH 7.5, White Lyophilized Powder)	8060-K	Recombinant Adiponectin (100 ng/ml)	1
		Assay Buffer (as above)	4
Quality Controls 1 & 2 (pH 7.5, Brown)	6300-K	Recombinant Adiponectin	1
		Assay Buffer (as above)	4
Adiponectin Antibody (pH 7.4, Blue)	1060-HK	Adiponectin Antibody	1
		Assay Buffer (as above)	4
		Inert Coloring	1
Rabbit Carrier (pH 6.8, Colorless)	RC-HK	Assay Buffer (as above)	4
		Rabbit IgG	1
Precipitating Reagent (pH 7.4, Green)	PR-81HK	Goat anti Rabbit IgG Serum	1
		Miscellaneous Buffers/Salts	1
		Sodium Azide (NaN ₃)	2
		Inert Coloring	1

Hazardous Ingredients:

1. Linco Research is not aware of any hazards for this product.
2. Sodium Azide, 0.08%: CAS # 26628-22-8. See fire hazard and explosion information below.
3. ¹²⁵I-Adiponectin tracer, <3uCi /vial. Radioactive. Half life = 60 days. Emits gamma rays. See health hazard data below.
4. Refer to ingredients and hazard information for Assay Buffer (above).

Fire Hazard and Explosion Information:

The above listed component contains sodium azide. Sodium azide may react with lead and copper plumbing to form highly explosive metal azides. If discarded into the sink, flush with a large volume of water to prevent azide build-up.

Health Hazard Data:

Item number 9060 contains ^{125}I -Adiponectin Tracer. This radioactive material is only for *in vitro* clinical or laboratory tests not involving internal or external administration to humans or animals. Its receipt, acquisition, possession, use and transfer are subject to the regulations of and with the general license from the US NRC or the State with which the US NRC has entered into agreement for the exercise of regulatory authority. Immediately upon receipt of this product, check for breakage and verify the contents as per the package list. Should there be breakage or questions regarding the contents, please immediately notify your supplier. Reagents should be stored and used only at clean, designated work stations of the laboratory. Although exposure to radiation from the small amount of radioactive material supplied is negligible, it is good practice to designate a storage area at least 10 feet away from any work station, if practical. Furthermore, persons under the age of 18 should not be permitted to handle radioactive material or enter a work area where it is present. The pipetting of radioactive material by mouth should not be permitted. Smoking, eating or drinking while performing tests involving radioactive material should not be permitted. Persons handling radioactive materials should wash their hands immediately after handling and prior to leaving the laboratory.

Appropriate handling of toxic chemicals in laboratories is essential. Periodic review of the safeguards must be ensured. Appropriate emergency procedures and equipment should be in place and their use should be reviewed. Laboratory technicians should be aware of the potential toxicity and rapidity of action, and signs and symptoms of poisoning with this compound.

Emergency and First Aid Procedures:

Tracer Exposure:

- Ingestion: Obtain immediate medical attention.
- Eyes: Immediately flush eyes with water.
- Skin: Wash skin with soap and plenty of water.

Spill Procedures:

Should there be a spill of radioactive material, the following clean-up procedure is recommended. While wearing gloves, blot the spillage with a paper towel. Wash the contaminated area with a detergent until background cpm is achieved. Contaminated towels and gloves should be disposed of as radioactive waste.

Storage and Disposal:

Storage: Upon arrival, store all components at 2-8°C. Refer to kit protocol for prolonged storage (>2 weeks).

Disposal: All radioactive materials must be disposed of in accordance with the prevailing regulations and guidelines of the agencies holding jurisdiction over the laboratory. Containers and assay tubes with residual radioactivity must be placed in a radioactive waste receptacle after radioactive labels are removed or defaced.

Protective Equipment:

Ventilation: Provide local exhaust or process enclosure ventilation to meet the published exposure limits.

Clothing and Gloves: Wear appropriate protective clothing and equipment to prevent repeated or prolonged contact with this substance. Protective clothing should meet the requirements for personal protective equipment. This clothing should include a lab coat and protective gloves.

Eye protection should always be worn when working with chemicals.

Disclaimer:

©2007 Millipore Corporation. All rights reserved. The above information is believed to be current and accurate; however, Millipore makes no warranty with respect to such information and assumes no liability for any loss or injury which may result from the use of this information. Users should conduct their own investigations to determine the suitability of the information.